

**5.4 CREW STEP PARTS LIST***P11.05.24*

| Qty<br>-015 | Qty<br>-016 | Qty<br>-025 | Qty<br>-026 | Qty<br>-035 | Qty<br>-036 | Part Number   | Description                    |
|-------------|-------------|-------------|-------------|-------------|-------------|---------------|--------------------------------|
| X           |             |             |             |             |             | D206-628-015  | CREW STEP, LH 206A/B           |
|             | X           |             |             |             |             | D206-628-016  | CREW STEP, RH 206A/B           |
|             |             | X           |             |             |             | D206-628-025  | CREW STEP, LH 206L/L-1/L-3/L-4 |
|             |             |             | X           |             |             | D206-628-026  | CREW STEP, RH 206L/L-1/L-3/L-4 |
|             |             |             |             | X           |             | D206-628-035  | CREW STEP, LH 407              |
|             |             |             |             |             | X           | D206-628-036  | CREW STEP, RH 407              |
|             |             |             |             | 2           | 2           | D2731-3RG     | MOUNTING LUG                   |
| 2           | 2           | 2           | 2           |             |             | D2731-7RG     | MOUNTING LUG                   |
|             |             |             |             | 2           | 2           | D3394-1RG     | MOUNTING LUG                   |
| 2           | 2           | 2           | 2           |             |             | D3394-3RG     | MOUNTING LUG                   |
|             |             | 1           |             | 1           |             | D4308-041     | CREW STEP, LH                  |
|             |             |             | 1           |             | 1           | D4308-042     | CREW STEP, RH                  |
| 2           | 2           | 2           | 2           | 2           | 2           | D4309-1       | BUSHING                        |
| 1           |             |             |             |             |             | D4357-041     | CREW STEP, LH                  |
|             | 1           |             |             |             |             | D4357-042     | CREW STEP, RH                  |
|             |             | 4           | 4           |             |             | AN4-11A       | BOLT                           |
| 4           | 4           | 4           | 4           | 4           | 4           | AN4-12A       | BOLT                           |
| 2           | 2           | 2           | 2           | 2           | 2           | AN4-15A       | BOLT                           |
| 6           | 6           | 6           | 6           | 6           | 6           | MS21042-4     | NUT                            |
| 6           | 6           | 6           | 6           | 6           | 6           | NAS1149D0463J | WASHER (AN960JD416)            |

**5.5 MAINTENANCE STEP PARTS LIST**

| Qty<br>-017 | Qty<br>-018 | Qty<br>-027 | Qty<br>-028 | Qty<br>-037 | Qty<br>-038 | Part Number   | Description                           |
|-------------|-------------|-------------|-------------|-------------|-------------|---------------|---------------------------------------|
| X           |             |             |             |             |             | D206-628-017  | MAINTENANCE STEP, LH 206A/B           |
|             | X           |             |             |             |             | D206-628-018  | MAINTENANCE STEP, RH 206A/B           |
|             |             | X           |             |             |             | D206-628-027  | MAINTENANCE STEP, LH 206L/L-1/L-3/L-4 |
|             |             |             | X           |             |             | D206-628-028  | MAINTENANCE STEP, RH 206L/L-1/L-3/L-4 |
|             |             |             |             | X           |             | D206-628-037  | MAINTENANCE STEP, LH 407              |
|             |             |             |             |             | X           | D206-628-038  | MAINTENANCE STEP, RH 407              |
| 2           | 2           |             |             | 2           | 2           | D2731-3RG     | MOUNTING LUG                          |
|             |             | 2           | 2           |             |             | D2731-7RG     | MOUNTING LUG                          |
| 2           | 2           |             |             | 2           | 2           | D3394-1RG     | MOUNTING LUG                          |
|             |             | 2           | 2           |             |             | D3394-3RG     | MOUNTING LUG                          |
| 2           | 2           | 2           | 2           | 2           | 2           | D4309-1       | BUSHING                               |
|             |             | 1           |             | 1           |             | D4342-041     | MAINTENANCE STEP, LH                  |
|             |             |             | 1           |             | 1           | D4342-042     | MAINTENANCE STEP, RH                  |
| 1           |             |             |             |             |             | D4358-041     | MAINTENANCE STEP, LH                  |
|             | 1           |             |             |             |             | D4358-042     | MAINTENANCE STEP, RH                  |
| 4           | 4           | 4           | 4           | 4           | 4           | AN4-12A       | BOLT                                  |
|             |             | 4           | 4           |             |             | AN4-13A       | BOLT                                  |
| 2           | 2           | 2           | 2           | 2           | 2           | AN4-15A       | BOLT                                  |
| 6           | 6           | 6           | 6           | 6           | 6           | MS21042-4     | NUT                                   |
| 6           | 6           | 6           | 6           | 6           | 6           | NAS1149D0463J | WASHER (AN960JD416)                   |

• COPYRIGHT © 2005 BY DART AEROSPACE USA, INC. •  
 THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED  
 OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.

**PRELIMINARY ISSUE**
 Revision: **G**  
 Date: 11.02.25

Rev PG1